

**Note:** Any visibly naked windings can be insulated with tape and air drying lacquer. Check the field coil again after the insulating operation.

#### **D. Testing Power Output of Starter**

Fix the starter assembly on a suitable test stand: Operate and brake-test the starter.

The test must be made with a well charged battery with a voltage of 12 volt and a capacity of 135 Ah (see Job No. 15-0).