

Group 03 - Moving Parts

Job No.	Operations	Page
03-0	Technical Data, Measures and Adjusting Values	03-0/1
03-1	Removal and Installation of Pulley on Crankshaft, OM 636	03-1/1
03-2	Removal and Installation of Pulley and Counterweight on Crankshaft, OM 621	03-2
03-3	Removal and Installation of Front Seal Ring for the Crankshaft, OM 621	03-3/1
03-5	Removal and Installation of Crankshaft with Flywheel	03-5/1
	A. OM 636	03-5/1
	B. OM 621	03-5/5
03-6	Grinding of Crankshaft	03-6/1
03-7	Balancing Crankshaft	03-7/1
	A. OM 636	03-7/1
	B. OM 621	03-7/1
03-8	Re-balancing new Flywheel, OM 621	03-8/1
03-9	Re-bedding of Crankshaft	03-9/1
03-11	Removal and Installation of Pistons with Connecting Rods	03-11/1
	A. OM 636	03-11/1
	B. OM 621	03-11/5
03-13	Repairing and Re-bushing of Connecting Rods	03-13/1
03-15	Fitting Pistons and Rings into Cylinders	03-15/1
03-16	Removal and Installation of Flywheel	03-16/1
	A. OM 636	03-16/1
	B. OM 621	03-16/3
03-17	Removal and Installation of Annular Grooved Bearing and Locking Ring in Crankshaft	03-17/1
03-18	Replacing Ring Gear of Flywheel	03-18/1
03-19	Grinding Clutch Surface of Flywheel	03-19/1