

Table 3

MOVING PARTS

Group 03

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	121 030 09 97	Set of crankshaft bearing shells Interior dia. 69.00 mm = repair size IV	1))))) option-) al)
-	621 030 05 97	Set of crankshaft bearing shells Interior dia. 69.00 mm = repairs size IV	1))))))
-	121 033 18 01	Crankshaft bearing shell) with)	4) option-) ready) al) for
-	621 033 04 01	Crankshaft bearing shell) groove)	4) al) installa-)) tion
-	121 033 18 02	Crankshaft bearing shell) without)	2) option-)) al)
-	621 033 04 02	Crankshaft bearing shell) groove)	2) al)
<u>CONNECTING ROD</u>				
25	121 030 15 20	Connecting rod without bearing	4	
26	186 038 07 50	Connecting rod bushing	4	
27	121 038 03 71	Connecting rod screw	8	
28	182 038 00 72	Nut	8	
-	186 038 08 50	Connecting rod bushing Outer dia. 28.5 mm	4	for repair design
29	121 038 28 10	Connecting rod bearing shell upper half Interior dia. 52.00 mm = standard	4)) optional) ready for
-	121 038 07 10	Connecting rod bearing shell upper half Interior dia. 52.00 mm = standard	4) installa-))

Table 3

MOVING PARTS

Group 03

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	121 038 29 10	Connecting rod bearing shell upper half Interior dia. 51,75 mm=rep. size I	4))))) option- al)
-	121 038 08 10	Connecting rod bearing shell upper half Interior dia. 51.75mm=rep. size I	4))))))
-	121 038 30 10	Connecting rod bearing shell upper half Interior dia. 51.50 mm=rep. size II	4))))) option- al)
-	121 038 09 10	Connecting rod bearing shell upper half Interior dia. 51.50 mm=rep. size II	4))))))
-	121 038 31 10	Connecting rod bearing shell upper half Interior dia. 51.25 mm=rep. size III	4))) ready) option- al) for installa- tion
-	121 038 10 10	Connecting rod bearing shell upper half Interior dia. 51.25 mm=rep. size III	4))))))
-	121 038 32 10	Connecting rod bearing shell upper half Interior dia. 51.00 mm=rep. size IV	4))))) option- al)
-	121 038 11 10	Connecting rod bearing shell upper half Interior dia. 51.00 mm=rep. size IV	4))))))
30	121 038 28 11	Connecting rod bearing shell lower half Interior dia. 52.00 mm = standard	4))))) option- al)
-	121 038 07 11	Connecting rod bearing shell lower half Interior dia. 52.00 mm = standard	4))))))

Table 3

MOVING PARTS

Group 03

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	121 038 29 11	Connecting rod bearing shell lower half Interior dia. 51.75 mm=rep. size I	4))))))) option- al)
-	121 038 08 11	Connecting rod bearing shell lower half Interior dia. 51.75 mm=rep. size I	4))))))))))
-	121 038 30 11	Connecting rod bearing shell lower half Interior dia. 51.50 mm=rep. size II	4))))))) option- al)
-	121 038 09 11	Connecting rod bearing shell lower half Interior dia. 51.50 mm=rep. size II	4))))))) ready) for
-	121 038 31 11	Connecting rod bearing shell lower half Interior dia. 51.25 mm=rep. size III	4))))))) option- al)
-	121 038 10 11	Connecting rod bearing shell lower half Interior dia. 51.25 mm=rep. size III	4))))))))))
-	121 038 32 11	Connecting rod bearing shell lower half Interior dia. 51.00 mm=rep. size IV	4))))))) option- al)
-	121 038 11 11	Connecting rod bearing shell lower half Interior dia. 51.00 mm=rep. size IV	4))))))))))