

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
27	-	Tapered roller bearing 32303 DIN 720	2	
28	180 334 00 62	Intermediate ring (for front steering knuckle, left)	1	
29	180 334 01 62	Intermediate ring (for front steering knuckle, right)	1	
30	120 334 03 15	Washer (for steering knuckle without locking groove)	2	
31	120 334 07 72	Clamping nut M 16 x 1 (for left and right steering knuckle)	2	
33	120 990 13 20	Hex. -hd. socket screw M 7	2	
34	120 330 01 57	Wheel cap with contact spring	2	
34a	-	Grooved guide pin 4 x 10 DIN 1474 Ms	2	for radio inter- ference sup- pression
35	180 421 08 01	Brake drum	2	
36	120 990 00 59	Sph. collar nut (for brake drum at wheel pin, front wheel hub)	4	see also group 35 and 40
<u>WISHBONE, BOTTOM</u>				
37	120 330 12 08	Wishbone, bottom, left	1	
38	120 330 13 08	Wishbone, bottom, right	1	
39	120 990 10 20	Cylindr. screw	8	

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
40	120 333 02 30	Pin	2	
41	120 333 01 80	Sealing ring	4	)
42	120 333 02 48	Threaded bushing (left, rear and right, front)	2	)
43	120 333 03 48	Threaded bushing (left, front and right, rear)	2	) for wishbone, inner
44	120 997 00 88	Grease fitting	4	)
45	120 333 04 74	Threaded pin with lubricating groove	2	)
46	181 333 01 80	Sealing ring	4	) for wishbone, bottom, at
47	181 990 00 55	Castle nut	2	) steering
48	-	Cotter pin 3x35 DIN 94	2	) knuckle support
		<u>WISHBONE, TOP</u>		)
49	120 330 04 07	Wishbone, top, left	1	
50	120 330 05 07	Wishbone, top, right	1	
51	120 333 00 30	Pin	2	
52	120 333 01 80	Sealing ring	4	)
53	120 333 02 48	Threaded bushing (left, front and right, rear)	2	)
54	120 333 03 48	Threaded bushing (left, rear and right, front)	2	) for wishbone, inner
55	-	Grease fitting B 8 DIN 71412	4	)
56	120 333 05 48	Threaded bushing with lubricating groove	2	
57	120 333 03 74	Eccentric pin	2	
58	181 333 01 80	Sealing ring	4	
59	120 990 13 40	Washer	2	