

Table 6

## FUEL FEED PUMP AND SUCTION NOISE DAMPER

Group 09

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
42	180 091 01 80	Sealing flange (between intermediate flange and cylinder crankcase)	1	)for inter- )mediate flange )at cylinder )crankcase
43	180 090 01 44	Intermediate flange (at cylinder crankcase)	1	
44	180 091 01 50	Bushing	1	
45	180 091 00 91	Sleeve	1	
46	-	Washer 8, 4 DIN 125	1	
47	-	Hex. -hd. socket screw M 8x30 DIN 912-6 G	2	
48	180 091 01 08	Plug (for fuel pump drive)	1	
<u>SUCTION NOISE DAMPER</u>				
50	001 094 22 02	Damper filter with Pico element	1	
51	000 094 39 06	Cover with sealing ring	1	
52	000 094 36 80	Rubber sealing ring (between cover and filter housing)	1	
53	000 094 37 80	Rubber sealing ring (between cover and Pico element)	1	
54	000 094 01 55	Spring lock	4	
55	000 094 38 04	Pico element	1	

Table 6

## SUCTION NOISE DAMPER

Group 09

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
56	000 094 37 80	Rubber sealing ring (in filter housing between Pico element)	1	
57	000 094 17 41	Support with rubber sleeve	1	
58	000 094 38 80	Rubber sleeve (for damper filter at carburettor)	1	
59	000 094 39 80	Rubber plate	6	)
60	000 094 00 76	Washer	3	) for support
61	-	Castle nut M 6 DIN 935-5 S	3	) at damper
62	-	Cotter pin 1, 5x15 DIN 94	3	) filter
63	-	Washer 8, 4 DIN 125	4	)
64	-	Hex. nut M 8 AGGN 14440-6 S	4	) for damper
				) filter at
				) suction tube