



Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>BATTERY, STARTING CABLE</u>		
1	000 541 46 01	Battery	1	
2	121 540 01 23	Mounting frame	1	
3	120 541 01 24	Tightening screw	2) for battery mounting)
4	-	Lock washer B 6 DIN 127	2	
5	-	Hex. nut M 6 DIN 934-5 S	2	
6	180 540 00 30	Starting cable (from +pole to starter motor)	1	
7	136 546 00 35	Rubber protective cap (for starting cable)	1	
8	180 540 00 31	Ground cable (from -pole battery to clutch housing)	1	
9	186 997 07 81	Rubber grommet (for starting cable through partition)	1	
		<u>CABLES</u>		
15	121 540 01 05	Main cable set	1	
16	000 545 06 28	Housing, lower part with socket	1	
17	000 545 00 80	Shim	1	
18	121 540 01 07	Tail light cable set	1	
19	180 540 00 08	Cable set (from generator to governor)	1	