



Table 28

STEERING

Group 46

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>STEERING</u>		
1	120 460 31 01	Steering without pitman arm	1	
2	120 462 05 50	Bushing, top and bottom	2	
3	120 460 16 08	Steering worm with nut and tapered roller bearing	1	
4	000 981 03 18	Tapered roller bearing	2	
5	186 460 01 11	Steering shaft with ball socket	1	
6	120 462 01 37	Ball socket	1	
7	120 461 04 06	Adjusting ring	1	
8	120 990 05 51	Hex. nut (for arresting adjusting ring)	1	
9	-	Sealing ring B 20 x 32 x 7 DIN 6504 (in adjusting ring)	1	
10	000 997 48 46	Sealing ring (for steering shaft at steering housing, bottom)	1	
13	120 461 05 80	Gasket (for housing cover at steering housing)	1	
14	186 461 07 05	Steering housing cover	1	
15	-	Lock washer B 8 DIN 127 (for steering housing cover at steering housing)	4	

10/024

Table 28

STEERING

Group 46

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	-	Hex. -hd. screw M 8x20 DIN 933-8 G	2)for steering)housing cover)at steering)housing
16a	-	Hex. -hd. screw M 8x25 DIN 933-8 G	2	
17	120 462 01 85	Pressure sleeve	1	
18	120 993 24 01	Pressure spring	1	
19	120 461 01 08	Pressure screw	1	
20	120 990 04 51	Hex. nut	1	
21	186 460 05 15	Cable tube	1	
22	120 997 11 40	Sealing ring (at cable tube, top)	1	
23	-	Screw plug AM 10x1 DIN 7604 (for locking steering housing cover after adjustment of front wheels)	1	
		<u>PITMAN ARM</u>		
25	120 463 05 01	Pitman arm	1	
26	-	Castle nut M 22x 1,5 DIN 937-5 S	1)for pitman arm)at steering
27	-	Cotter pin 5x40 DIN 94	1	
		<u>STEERING COUPLING</u>		
28	120 460 08 10	Steering coupling with ground connection	1	