

Table 35

## BODY, FRONT WALL AND REAR PART

Group 62/64

| Fig. No.         | No. of spare part | Denomination                                      | Quantity | Remarks   |
|------------------|-------------------|---|----------|---|
| -                | 10 120 621 04 13  | Threaded plate, bottom, right<br>(for door hinge) | 1        |   |
| 85               | 10 120 620 01 72  | Reinforcement plate, outside, left                | 1        | )hinge side<br>)on angle plate                                    |
| -                | 10 120 620 02 72  | Reinforcement plate, outside, right               | 1        |   |
| <u>REAR PART</u> |                   |   |          |   |
| 88               | 10 120 640 00 05  | Rear part, shell                                  | 1        |   |
| 89               | 10 120 640 01 59  | Inner panel<br>with wheel house, left             | 1        |   |
| 90               | 10 120 640 02 59  | Inner panel<br>with wheel house, right            | 1        |   |
| 91               | 10 120 640 01 66  | Inner panel, left                                 | 1        | )part of roof<br>)frame, top, up<br>)to wheel arch,<br>rear       |
| -                | 10 120 640 02 66  | Inner panel, right                                | 1        |   |
| 91a              | 10 120 890 01 10  | Bracket<br>(for car jack wrench, front)           | 1        | bracket for car<br>jack wrench, rear<br>see group 61              |
| 92               | 10 120 640 01 75  | Angle plate, left                                 | 1        | )part of wheel<br>)arch up to roof<br>)for fixing<br>)locking pin |
| -                | 10 120 640 02 75  | Angle plate, right                                | 1        |   |
| 93               | 10 120 761 01 36  | Threaded plate<br>(for locking eye)               | 2        |   |
| 94               | 10 120 646 01 63  | Cover plate, left                                 | 1        | )between inner<br>)panel and roof<br>)panelling                   |
| -                | 10 120 646 02 63  | Cover plate, right                                | 1        |   |

| Fig. No. | No. of spare part | Denomination   | Quantity | Remarks                      |
|----------|-------------------|--|----------|------------------------------|
| 95       | 10 120 640 00 71  | Center piece, bottom   | 1        |                              |
| 96       | 10 120 647 01 34  | Cover plate, left  | 1        | )for bracket,                |
| 97       | 10 120 647 02 34  | Cover plate, right   | 1        | )bumper, rear                |
| 98       | 10 120 646 01 18  | Angular reinforcement, left  | 1        | )                            |
| -        | 10 120 646 02 18  | Angular reinforcement, right   | 1        | )between luggage compartment |
|          |                   | <u>TOP</u>   |          | )cover plate and wheel house |
| 99       | 10 121 650 00 70  | Top panel<br>(from engine hood to flap)                                | 1        |                              |
| 100      | 10 120 657 00 09  | Top panel<br>(panel from windscreen, top, to rear wall window)         | 1        |                              |
| 101      | 10 120 650 01 72  | Front wall frame, external<br>(from engine hood to top, external only) | 1        |                              |
| 102      | 10 180 657 00 71  | Center piece, rear, top<br>(from rear wall window to flap)             | 1        |                              |
| 103      | 10 120 650 01 11  | Top frame, left  | 1        |                              |
| -        | 10 120 650 02 11  | Top frame, right   | 1        |                              |