



Table 9

OIL PUMP AND LUBE OIL LINES

Group 18

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>OIL PUMP</u>		
1	121 180 09 01	Oil pump, complete	1	
2	180 181 01 50	Bearing bushing, top	1	
3	121 180 03 07	Drive shaft with gear	1	
4	121 180 01 08	Oil pump shaft with gear	1	
5	121 181 00 95	Bracket	1	
6	121 180 06 52	Suction basket	1	
7	121 186 00 80	Gasket	1)
8	-	Hex. -hd. screw M 6x22 DIN 931-8 G	1)
9	-	Hex. -hd. screw M 6x35 DIN 931-8 G	2) for lower part) and suction) basket at) upper part
10	-	Hex. -hd. screw M 6x55 DIN 931-8 G	2)
11	-	Lock washer B 6 DIN 137	5)
12	-	Hex. nut M 6 DIN 934-5 S	4)
13	180 091 01 12	Cam (on oil pump drive shaft for fuel feed pump)	1	
14	-	Dowel pin 4x18 DIN 1481 (for cam)	1	
15	-	Lock washer B 8 DIN 137 (for oil pump at cylinder crank- case)	1	

Group 18

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	-	Hex. -hd. screw M 8x18 DIN 933-8 G (for oil pump at cyl. crankcase)	1	
		<u>OIL FILTER</u>		
-	000 184 58 01	Oil filter, complete)) optional	1	
20	121 180 01 10	Oil filter, complete)	1	
21	121 184 01 08	Oil filter housing, upper part	1	
22	181 184 00 30	Valve cone	2	
23	181 993 06 01	Spring	2	
24	-	Sealing ring D 18x22 DIN 7603 A1	2	
25	181 184 00 56	Screw plug	2	
26	181 184 01 17	Screwed nipple	1	
27	000 184 35 01	Lube oil plate-type filter with Micronic element	1	
28	000 184 05 12	Coil	1	
29	000 184 00 15	Discharge ring with sealing ring	1	
30	000 184 06 80	Sealing ring	1	
31	000 184 22 25	Filter element (Micronic element)	1	
32	000 990 49 51	Hex. nut M 14 x 1,5	1	