

Table 1

ENGINE HOUSING

Group 01

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
31	180 011 01 79	Gasket	1)for locking
32	-	Hex. -hd. socket screw M 6x12 DIN 912-8 G	4)cover at)cylinder)crankcase
-	180 052 10 06	Bushing (for intermediate gear shaft, rear)	1	see group 05
-	180 150 01 07	Bearing with bushing	1	see group 15
33	180 011 06 05	Intermediate plate (for cylinder crankcase, starter motor)	1	
34	-	Hex. -hd. screw M 10x15 DIN 933-8 G	2)for intermed.)plate at)cylinder
34a	-	Lock washer B 10 DIN 137	2)crankcase
		<u>OIL PAN</u>		
35	121 010 10 13	Oil pan with threaded bushing	1	
36	180 010 00 66	Guide tube (in oil pan for oil dipstick)	1	
37	180 997 00 40	Sealing ring (for bleeding filter)	1	
38	121 010 00 72	Oil dipstick with bleeding filter	1	
39	-	Sealing ring C 26x32 DIN 7603 Cu-Asb.	1)for oil)discharge,)oil pan
40	136 997 12 30	Screw plug	1	
41	-	Washer 6, 4 DIN 433 (for oil pan at cylinder crankcase)	18	