

|         |
|---------|
| Job No. |
| 46-2    |

## **Removal and Installation of Steering Wheel**

### **I. Models 180, 180 a, 180 D, 190 D, 190 SL, 220 a, 219, 220 S, and 220 SE**

The removal and installation procedures for the steering wheel are the same as for Model 190.

### **II. Models 180 b, 180 Db, and 190 Db**

The removal and installation procedures for the steering wheel are the same as for Model 190 b.

|         |
|---------|
| Job No. |
| 46-3    |

## **Checking of Play in Steering Assembly Units**

On Models 180 to 220 SE the checking procedures for the play in the steering assembly units are the same as for Model 190.