


Job No.
32-6

## Removal and Installation of Torsion Bar

The removal and installation procedures for the torsion bar on Models 180 to 220 SE are the same as on Model 190 with the difference, however, that on Model 190 SL the attachment of the torsion bar to the chassis base panel differs from that used on the other models (Fig. 32-6/1).



Different torsion bars have been installed on the individual models (see Table).

### List of Torsion Bars

Model	Torsion bar		Remarks
	Part No.	Diameter	
180, 180 D	120 321 05 07	19 mm	On Model 180 D 1st Version
180 a, 180 b, 180 D, 180 Db, 190, 190 b, 190 D, 190 Db	121 321 00 07	19 mm	On Model 180 D 2nd Version
190 SL	121 321 02 07	20 mm	
220 a	180 321 05 06	20 mm	1st Version
220 a, 219, 220 S, 220 SE	180 321 07 07	20 mm	On Model 220 a 2nd Version On Model 220 SE 1st Version
220 SE	180 321 08 07	22 mm	2nd Version