

Job No.
46-2

Removal and Installation of Steering Wheel

I. Models 180, 180 a, 180 D, 190 D, 190 SL, 220 a, 219, 220 S, and 220 SE

The removal and installation procedures for the steering wheel are the same as for Model 190.

II. Models 180 b, 180 Db, and 190 Db

The removal and installation procedures for the steering wheel are the same as for Model 190 b.

Job No.
46-3

Checking of Play in Steering Assembly Units

On Models 180 to 220 SE the checking procedures for the play in the steering assembly units are the same as for Model 190.