

Job No.
82-3

Removal and Installation of Left or Right Flash Signal with Clearance Light

I. Models 180, 180 a, 180 b, 180 D, 180 Db, 190 D, 190 Db

The removal and installation procedures for the flash signal and clearance light are the same as on Model 190.

II. Model 190 SL

In the case of standard headlights the flash signal and clearance light are installed in a fitted light below the headlight and in the case of headlights with sealed-beam unit the flash signal, clearance and parking lights are installed in this fitted light.

III. Models 220 a, 219, 220 S, 220 SE

On these models the flash signal and the clearance light are located on the fender (see Figs. 82-3/1 and 82-3/2).




Fig. 82-3/1

- 1a Flash signal and clearance light, right
- 2 Cage clamp with nut M 6
- 3 Rubber pad
- 4 Weather strip
- 5a Transparent pane, right
- 6 Rubber grommets
- 7 Oval head countersunk screw M 4




Fig. 82-3/2

- 1b Flash signal and clearance light, left
- 5b Transparent pane, left
- 8 Rubber ring