


D. Fuel Pass Filter with Change-Over Cock

When the filter is removed and installed both the reserve fuel line (2) and the actuating rod (15) on the pass filter must be removed and installed (Fig. 47-6/2).

Fig. 47-6/2



Job No.

47-8

Checking of Fuel Feed Pump on Model 220 SE

See Workshop Manual Passenger Car Models as from August 1959, Job No. 00-15, Section C.