

D. Fuel Pass Filter with Change-Over Cock

When the filter is removed and installed both the reserve fuel line (2) and the actuating rod (15) on the pass filter must be removed and installed (Fig. 47-6/2).




Fig. 47-6/2

- 1 Fuel line
- 2 Reserve fuel line
- 3 Seal
- 4 Fuel pass filter with change-over cock
- 5 Flexible hose
- 6 Hexagon nut
- 7 Lock washer
- 8 Hexagon screw
- 9 Wire clamp with wing nut and dome seal
- 10 Filter cup
- 11 Filter element
- 12 Snap ring
- 13 Seal
- 14 Lever
- 15 Actuating rod
- 16 Cotter pin
- 17 Washer
- 18 Spring washer
- 19 Spring washer
- 20 Washer
- 21 Cotter pin

Z-592

Job No.
47-8

Checking of Fuel Feed Pump on Model 220 SE

See Workshop Manual Passenger Car Models as from August 1959, Job No. 00-15, Section C.