

Lubricating Points

As the cars of Type 220a are not provided with a central lubricating system, the various lubricating points are equipped with pressure grease fittings.

Pressure Grease Fittings on the Car	Number
Front Axle	22
a) Right and left-hand control arm supports top 2 each	4
bottom 2 each	4
b) King pins in steering knuckles, right and left-hand, 1 each	2
c) Threaded bolts in steering knuckle supports, right and left-hand top 1 each	2
bottom 1 each	2
d) Ends of center as well as right and left-hand outer tie rods 2 each	6
e) End of intermediate steering arm	1
f) End of steering shock absorber	1
Pedal Linkage	2
Propeller Shaft	4
a) In center at intermediate bearing	2
b) Rear end at keyway	1
c) Rear end at spider	1
Total Amount of Lubricating Points	28

Details regarding type and make of approved lubricants are given in the Instruction Manual. Upon request our department Export-Service will furnish exhaustive information in this matter.

