



# Lubricating Chart for Type 220

Cooling water filler neck



Distributor grease fitting




Engine oil filler neck




Central lubricating container



Battery





Support of steering column gear shift



Transmission oil filler screw



Propeller shaft lubricating nipple





Distributor



Generator



Radiator water drain cock




Rear axle oil filler screw



Rear axle oil level screw




Fuel filler neck



Front wheel bearing




Steering housing




Engine oil drain plug




Engine water drain cock



Engine oil dip stick



Brake fluid container



Engine oil filter



Lubricating nipple on three-arm flange