



Table 6

## FUEL FEED PUMP

Group 09

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>FUEL FEED PUMP</u>		
1	000 091 53 01	Fuel feed pump with dust filter	1	
2	000 993 09 10	Return spring for hand lever	1	
3	000 994 00 41	Circlip (for hand lever)	1	
4	000 091 01 18	Joint piece (for pump lever)	1	
5	000 091 02 07	Pump lever	1	
6	000 091 00 50	Bushing )	1	
7	000 091 00 21	Shaft )for pump lever	1	
8	000 091 08 15	Pressure spring )	1	
9	000 091 16 15	Diaphragm spring	1	
10	000 091 00 36	Oil protective plate	1	
11	000 091 01 15	Spring (for oil protective plate)	1	
12	000 091 04 28	Diaphragm, complete	1	
13	-	Countersunk screw AM 3, 5x8 DIN 63-4 S (for valve plate)	3	
14	-	Toothed washer V 3, 7 DIN 6797	3	
15	000 091 04 29	Valve plate	1	

Table 6

## FUEL FEED PUMP

Group 09

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	000 091 01 80	Gasket (for valve plate)	1	
17	000 091 04 19	Valve spring (for intake and exhaust valve)	2	
18	000 091 00 29	Valve plate (for intake and exhaust valve)	2	
19	000 091 00 31	Valve seat (for intake valve)	1	
20	000 091 00 16	Spring cage (for exhaust valve)	1	
22	-	Lock washer B 5 DIN 127	6	)
23	-	Lens-hd. screw AM 5x15 DIN 85-4 S	6	)for upper part ) at lower part )
24	000 091 08 39	Strainer with pressure spring	1	
25	000 091 06 80	Gasket (for cap)	1	
26	000 091 01 46	Cap (for upper part)	1	
27	-	Sealing ring A 6x12 DIN 7603 fiber	1	) )for cap at ) upper part
28	-	Hex. -hd. screw M 6x12 DIN 931-8 G	1	)
29	-	Sealing ring A 8x12 DIN 7603 fiber (for screw plug at upper part)	1	

10/024

Table 6

## FUEL FEED PUMP

Group 09

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
30	000 091 03 56	Screw plug M 8 x 1 (for upper part)	1	
31	000 091 08 71	Water drain plug (at upper part)	1	
32	000 091 11 15	Pressure spring (for water drain plug)	1	
33	-	Sealing ring A 12x16 DIN 7603 hard fiber (for screw plug)	1	
34	-	Screw plug AM 12x1, 5 DIN 7604 (at upper part)	1	
35	-	Screwed nipple 6 DIN 7627	2	
36	-	Sealing ring A 12x16 DIN 7603 fiber	2	
36a	000 091 00 85	Bleeding filter (at fuel feed pump, lower part)	2	only valid for replacement delivery
37	181 091 00 80	Gasket	1	)
38	181 091 00 81	Insulating flange	1	)
39	181 091 00 80	Gasket	1	) for fuel feed pump at intermediate flange
40	-	Lock washer B 8 DIN 137	2	)
41	-	Hex. -hd. socket screw M 8x28 DIN 912-6 G	2	)

Table 6

## FUEL FEED PUMP AND SUCTION NOISE DAMPER

Group 09

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
42	180 091 01 80	Sealing flange (between intermediate flange and cylinder crankcase)	1	
43	180 090 01 44	Intermediate flange (at cylinder crankcase)	1	
44	180 091 01 50	Bushing	1	
45	180 091 00 91	Sleeve	1	
46	-	Washer 8, 4 DIN 125	1	)for inter- )mediate flange )at cylinder )crankcase
47	-	Hex. -hd. socket screw M 8x30 DIN 912-6 G	2	
48	180 091 01 08	Plug (for fuel pump drive)	1	
<u>SUCTION NOISE DAMPER</u>				
50	001 094 22 02	Damper filter with Pico element	1	
51	000 094 39 06	Cover with sealing ring	1	
52	000 094 36 80	Rubber sealing ring (between cover and filter housing)	1	
53	000 094 37 80	Rubber sealing ring (between cover and Pico element)	1	
54	000 094 01 55	Spring lock	4	
55	000 094 38 04	Pico element	1	