

Table 3

MOVING PARTS

Group 03

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
18	-	Fiber sealing ring 75 x 87 x 6 GL N 255 a (for crankshaft sealing in cylinder crankcase, rear)	1	
		<u>CRANKSHAFT BEARING</u>		
20	121 030 05 97	Set of crankshaft bearing shells Interior dia. 70 mm = standard	1))) option-) al)
-	621 030 00 97	Set of crankshaft bearing shells Interior dia. 70 mm = standard	1))))))
21	121 033 14 01	Crankshaft bearing shell) with)	4) option-) al)
-	621 033 00 01	Crankshaft bearing shell) groove)	4))))))
22	121 033 14 02	Crankshaft bearing shell) without)	2) option-) al)
-	621 033 00 02	Crankshaft bearing shell) groove)	2))) ready) for in-
-	121 030 06 97	Set of crankshaft bearing shells Interior dia. 69.75 mm = repair size I	1))))) option-) al)
-	621 030 01 97	Set of crankshaft bearing shells Interior dia. 69.75 mm = repair size I	1))))))))
-	121 033 15 01	Crankshaft bearing shell) with)	4) option-) al)
-	621 033 01 01	Crankshaft bearing shell) groove)	4))))))
-	121 033 15 02	Crankshaft bearing shell) without)	2) option-) al)
-	621 033 01 02	Crankshaft bearing shell) groove)	2))))))

Table 3

MOVING PARTS

Group 03

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	121 030 07 97	Set of crankshaft bearing shells Interior dia. 69.50 mm = repair size II	1))))) option- al)
-	621 030 02 97	Set of crankshaft bearing shells Interior dia. 69.50 mm = repair size II	1))))))))
-	121 033 16 01	Crankshaft bearing shell) with	4) option- al)
-	621 033 02 01	Crankshaft bearing shell) groove	4))))))
-	121 033 16 02	Crankshaft bearing shell) without	2) option- al)
-	621 033 02 02	Crankshaft bearing shell) groove	2))))))
-	121 030 08 97	Set of crankshaft bearing shells Interior dia. 69.25 mm = repair size III	1)) ready)) for) option- installa- al tion
-	621 030 03 97	Set of crankshaft bearing shells Interior dia. 69.25 mm = repair size III	1))))))))
-	121 033 17 01	Crankshaft bearing shell) with	4) option- al)
-	621 033 03 01	Crankshaft bearing shell) groove	4))))))
-	121 033 17 02	Crankshaft bearing shell) without	2) option- al)
-	621 033 03 02	Crankshaft bearing shell) groove	2))))))

10/024

Table 3

MOVING PARTS

Group 03

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	121 030 09 97	Set of crankshaft bearing shells Interior dia. 69.00 mm = repair size IV	1))))) option-) al)
-	621 030 05 97	Set of crankshaft bearing shells Interior dia. 69.00 mm = repairs size IV	1))))))
-	121 033 18 01	Crankshaft bearing shell) with)	4) option-) ready) al) for
-	621 033 04 01	Crankshaft bearing shell) groove)	4) al) installa-)) tion
-	121 033 18 02	Crankshaft bearing shell) without)	2) option-)) al)
-	621 033 04 02	Crankshaft bearing shell) groove)	2) al)
<u>CONNECTING ROD</u>				
25	121 030 15 20	Connecting rod without bearing	4	
26	186 038 07 50	Connecting rod bushing	4	
27	121 038 03 71	Connecting rod screw	8	
28	182 038 00 72	Nut	8	
-	186 038 08 50	Connecting rod bushing Outer dia. 28.5 mm	4	for repair design
29	121 038 28 10	Connecting rod bearing shell upper half Interior dia. 52.00 mm = standard	4)) optional) ready for
-	121 038 07 10	Connecting rod bearing shell upper half Interior dia. 52.00 mm = standard	4) installa-))