



Table 14

## TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>SHIFTING CONTROLS, TRANSMISSION</u>		
1	186 260 08 14	Transmission case cover, top with selector finger lever (without shifting finger lever) Exchange mounted plug in transmission case cover against reverse drive light switch and pressure pin.	1	
2	186 260 07 14	Transmission case cover	1	
3	153 992 00 05	Bushing	1	
4	136 265 00 48	Bar	1	)
5	186 261 00 52	Shim 0.2 mm thick )	a.r.	) stop for reverse drive gear
-	186 261 01 52	) optional Shim 0.5 mm thick )	a.r.	)
6	180 993 26 01	Pressure spring	1	
8	136 265 02 47	Guide pin	2	
9	183 265 00 46	Locking plate	1	
10	-	Hex. -hd. screw M 6 x 18 DIN 933-8 G	2	) )for locking )plate at trans-
11	-	Lock washer B 6 DIN 137	2	)mission case )cover, top
12	-	Hex. nut M 6 DIN 934-5 S	2	)
13	136 263 00 07	Shifting shaft	1	

Table 14

## TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
14	183 268 01 33	Shifting finger )	1	) on shifting shaft
-	186 268 00 33	) optional Shifting finger )	1	
15	183 268 00 52	Washer	1	
16	000 981 01 10	Needle bearing HK 12x19/16	2	
17	186 997 01 20	Cover	1	
18	-	Radial sealing ring A 12x22x7 DIN 6503	1	) for shifing shaft
19	-	Circlip 22x1 DIN 472	1	
20	186 260 02 79	Selector finger	1	
21	186 260 00 37	Selector lever	1	
22	186 260 01 50	Rubber ring	1	
23	-	Hex. -hd. screw M 6x25 DIN 931-8 G	1	) for clamping lever for selector finger
24	-	Lock washer B 6 DIN 127	1	
25	-	Hex. nut M 6 DIN 934-5 S	1	)
26	186 260 00 28	Guide plate	1	
27	136 990 82 40	Washer	2	) for guide plate at transmission
28	136 265 02 72	Nut M 8	2	
29	186 265 00 01	Shift fork (for 1st and 2nd gear)	1	
30	186 265 00 02	Shift fork (for 3rd and 4th gear)	1	

Table 14

## TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
31	186 993 13 01	Pressure spring	2	
32	-	Steel ball 8 mm III DIN 5401	2	
33	136 265 00 53	Spacer tube	2	
34	136 265 00 51	Spacer ring 0.3 mm thick	a.r.)	) optional
-	136 265 01 51	Spacer ring 0.5 mm thick	a.r.)	
-	136 265 02 51	Spacer ring 1.0 mm thick	a.r.)	
35	136 265 04 04	Shift rail (for 1st and 2nd gear)	1	
36	136 265 05 04	Shift rail (for 3rd and 4th gear)	1	
37	184 265 00 53	Spacer tube	2	
38	136 265 00 07	Rail end (for reverse gear)	1	
39	136 993 31 01	Pressure spring	1	
40	-	Steel ball 8 mm III DIN 5401	1 )	) for rail end ) for reverse gear
41	136 265 01 53	Spacer tube	1 )	
42	136 265 00 51	Spacer ring 0.3 mm thick)	a.r.)	
-	136 265 01 51	Spacer ring 0.5 mm thick) op- tional	a.r.)	
-	136 265 02 51	Spacer ring 1.0 mm thick)	a.r.)	
43	136 265 02 04	Shift rail (for reverse gear)	1	

Table 14

## TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
44	136 265 00 81	Key (for shift rail mounting)	1	
45	136 350 01 90	Fan (at transmission case cover, top)	1	
46	120 260 21 37	Lever (for shifting shaft)	1	
47	186 260 01 50	Rubber ring	1	
48	-	Hex. -hd. screw M 6x25 DIN 931-8 G	1	) ) for lever at shifting shaft
49	-	Lock washer B 6 DIN 127	1	
50	-	Hex. nut M 6 DIN 934-5 S	1	
51	186 261 01 79	Gasket (for transmission case cover, top)	1	
52	-	Lock washer B 8 DIN 137	4	)for transmission case cover, top at transmission case
53	-	Hex. -hd. screw M 8x30 DIN 931-8 G	4	
<u>SHIFTING, STEERING COLUMN</u>				
65	180 260 01 82	Shifting tube	1	
66	180 268 01 39	Guide pin	1	
67	186 997 00 82	Rubber ring	2	
68	186 268 02 73	Lock	1	
69	183 990 35 40	Shim	1	