



Table 50

REAR SEAT

Group 92

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>REAR SEAT</u>		
1	10 120 920 02 20	Rear seat cushion, ready for installation	1	state colour and body No. when ordering
2	10 120 920 01 22	Seat cushion frame, rear seat	1	
3	10 120 920 01 40	Spring core, rear seat cushion	1	
4	10 120 924 01 14	Rubber fiber layer (for rear seat cushion)	1	
5	000 984 20 61	Clamp (for layer at spring core)	24	
6	10 120 920 01 46	Cover (sewn) (for rear seat cushion)	1) state colour and body No. when ordering)
7	10 120 920 09 30	Rear seat back rest ready for installation	1	
8	10 120 920 06 32	Back rest frame, rear seat	1	
9	10 120 920 09 41	Spring core for rear seat back rest	1	
10	10 120 924 01 16	Rubber fiber layer, rear seat back rest	1	
11	000 984 20 61	Clamp (for layer at spring core)	14	
12	10 120 920 02 47	Cover (sewn) (for back rest, rear seat)	1	state colour and body No. when ordering
-	-	Washer A 6 DIN 9021	2)for rear seat
-	-	Lock washer B 6 DIN 127	2)back rest at
-	-	Hex. nut M 6 DIN 934-5 S	2)rear floor)

10/024

