

Table 2

ENGINE HOUSING

Group 01

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
80	121 016 03 20	Cylinder head gasket	1)
81	-	Hex. -hd. socket screw M 8x20 DIN 912-8 G	2)
82	-	Washer 8, 4 DIN 433	3)for cylinder)head at cylinder
83	-	Hex. -hd. socket screw M 8x30 DIN 912-8 G	1)crankcase)
84	186 990 09 40	Washer	6)
85	-	Hex. -hd. socket screw M 12x125 DIN 912-10 K	6)
		<u>CYLINDER HEAD COVER</u> <u>WITH BLEEDING</u>		
86	121 010 03 30	Cylinder head cover, complete	1	
87	136 501 00 54	Screwed cover (for filling in oil)	1	
88	180 997 02 40	Sealing ring 47x65x3 (for screwed cover)	1	
89	121 010 00 70	Bleeder pipe	1	
90	180 995 07 01	Tube clamp	2)for bleeder)pipe at cylind.
91	-	Lock washer B 6 DIN 127	2)head cover)up to engine
92	-	Hex. -hd. socket screw M 6x12 DIN 912-8 G	2)No.)65 00110

10/024

Table 2

ENGINE HOUSING

Group 01

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
93	-	Sealing ring A 16x22 DIN 7603 A1	1)for bleeder)pipe at cylinder)head cover
94	180 997 02 72	Screwed nipple	1)
95	180 010 00 94	Tightening screw (for cylinder head cover at cylinder head)	2	
96	-	Sealing ring C 8x14 DIN 7603 Cu-Asb.	2)for tightening)screw at)cylinder head
97	-	Lock washer 6 DIN 6799	2)cover
98	121 016 00 80	Gasket (for cylinder head cover)	1	
99	121 010 02 70	Bleeder pipe (from cyl. head cover to air filter)	1	
100	-	Box nut 13 M 22x1, 5 DIN 7606 (for bleeder pipe at cyl. head cover)	1	
101	180 997 10 82	Rubber hose	1)
102	-	Hose clamp S 5 N 262	1)for bleeder)pipe at cylinder)head cover
103	-	Hose strap 5x0, 35x200 N 263 (state length when ordering)	1)
104	180 010 00 40	Clamp for cylinder head cover	2	
105	-	Hex. -hd. socket screw M 12x105 DIN 912-10 K	4)for clamp resp.)cylinder head)at cylinder
106	-	Washer 13 DIN 433	4)crankcase