

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	-	Hex. -hd. screw M 8x20 DIN 933-8 G	2	)for steering )housing cover )at steering )housing
16a	-	Hex. -hd. screw M 8x25 DIN 933-8 G	2	
17	120 462 01 85	Pressure sleeve	1	
18	120 993 24 01	Pressure spring	1	
19	120 461 01 08	Pressure screw	1	
20	120 990 04 51	Hex. nut	1	
21	186 460 05 15	Cable tube	1	
22	120 997 11 40	Sealing ring (at cable tube, top)	1	
23	-	Screw plug AM 10x1 DIN 7604 (for locking steering housing cover after adjustment of front wheels)	1	
		<u>PITMAN ARM</u>		
25	120 463 05 01	Pitman arm	1	
26	-	Castle nut M 22x 1,5 DIN 937-5 S	1	)for pitman arm )at steering
27	-	Cotter pin 5x40 DIN 94	1	
		<u>STEERING COUPLING</u>		
28	120 460 08 10	Steering coupling with ground connection	1	

Table 28

## STEERING

Group 46

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
29	183 462 00 46	Joint disc	1	
30	153 540 00 42	Ground connection	1	
31	-	Hex. -hd. screw M 8x28 S DIN 931-8 G	4	) ) for joint disc
32	-	Castle nut M 8 DIN 937-5 S	4	) ) at flange
33	-	Cotter pin 2x18 DIN 94	4	)
34	-	Hex. -hd. screw M 8x35 DIN 931-8 G	2	) ) for steering coupling at
35	-	Lock washer B 8 DIN 127	2	) steering and
36	-	Hex. nut M 8 DIN 934-5 S	2	) steering column jacket
37	-	Lock washer B 10 DIN 127	3	) ) for steering
38	-	Hex. -hd. collar screw M 10x28 N 170 a - 8 G	3	) ) at front axle support
39	180 460 31 16	Jacket	1	
40	120 427 01 15	Pawl	1	
41	120 993 00 20	Reverse spring	1	
42	-	Rivet pin A 6 h11x20 DIN 7341	1	
43	120 460 40 09	Steering column jacket	1	
44	120 462 01 60	Sealing ring (for support, top)	1	
45	-	Annular grooved bearing 6004 X DIN 625	1	

Table 28

## STEERING

**Group 46**

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
46	180 540 00 09	Cable set	1	
47	120 990 00 77	Threaded pin (for jacket)	1	
48	120 993 08 01	Pressure spring (for steering column, top)	1	
		<u>STEERING WHEEL</u>		
49	120 464 04 01	Steering wheel, black )	1	
-	120 464 06 01	) optional Steering wheel, black )	1	
50	-	Key A 6 x 4 x 20 DIN 6885	1	)
51	120 994 03 12	Locking plate	1	) for steering
52	-	Hex. nut M 18x1,5 DIN 936-5 S	1	) wheel at
53	120 460 02 45	Contact plate	1	) steering column
54	181 464 00 71	Clamping screw	5	
55	-	Cylindr. screw AM 4x25 DIN 84-5 S	1	
56	-	Cylindr. screw AM 4x15 DIN 84-5 S	2	
57	-	Lock washer 4 N 55 a	2	
58	186 460 03 40	Signal ring	1	
59	181 460 04 46	Stop lever	1	
60	181 464 00 90	Release spring	1	