

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
20	121 250 00 05	Clutch housing	1	
21	186 991 07 01	Cylindr. pin	1	
22	-	Stud bolt M 7x22 DIN 835-5 S	1)
23	121 990 00 05	Stud bolt	1)for bracket -)spring suspen-)sion
27	120 254 00 97	Sleeve at clutch housing	1	
28	120 254 00 58	Gasket holder	1)
29	-	Hex. -hd. screw M 6x12 DIN 933-8 G	4)for sleeve at)clutch housing)
30	-	Lock washer B 6 DIN 137	4)
31	120 251 00 71	Vent screw	1	
32	-	Sealing ring A 12x16 DIN 7603 A1	1	
33	121 490 01 44	Mounting plate (for exhaust muffler support)	1	
34	-	Lock washer B 12 DIN 127	4)
35	-	Hex. -hd. screw M 12x50 DIN 931-8 G	2)
36	-	Washer 13 DIN 125	4)for clutch)housing at)transmission
37	-	Hex. nut M 12 DIN 934-5 S	4)housing)
38	-	Hex. -hd. screw M 12x55 DIN 931-8 G	2)

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
39	180 250 00 56	Cover plate for clutch housing	1	
40	-	Hex. -hd. screw M 6x25 DIN 931-8 G	2)))for cover plate
41	-	Washer 6, 4 DIN 125	2) at clutch)housing
42	-	Lock washer B 6 DIN 127	2))
43	-	Hex. nut M 6 DIN 934-5 S	2)
44	121 250 01 15	Clutch throw-out bearing with throw-out unit	1	
45	121 254 00 10	Throw-out bearing	1	
46	180 293 01 11	Throw-out fork	1	
47	120 993 01 25	Spring clip (for throw-out fork at throw-out unit)	2	
48	-	Snap ring R 16 DIN 71805 (for throw-out fork at ball pin)	1	