

Table 4

TIMING

Group 05

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
58	180 053 06 60	Sealing ring	8	
59	180 053 01 27	Valve cone half	16	
60	121 053 01 62	Pressure ring		
		<u>ROCKER ARM</u>		
61	180 050 03 33	Rocker arm for intake	4	
62	180 055 01 50	Bushing	4	
63	180 055 05 71	Adjusting screw	4	
64	153 990 02 51	Hex. nut	4	
65	180 050 03 34	Rocker arm for exhaust	4	
66	180 055 01 50	Bushing	4	
67	180 055 04 71	Adjusting screw	4	
68	153 990 02 51	Hex. nut	4	
69	121 055 02 05	Rocker arm axis	2	
70	180 055 14 10	Rocker arm support (for cylinder 1 and 3)	2	
71	180 055 15 10	Rocker arm support (for cylinder 2 and 4)	2	
72	180 055 00 93	Yoke	4	
73	-	Washer 10, 5 DIN 433	4) for rocker arm support at cylinder head
74	180 055 01 75	Adjusting sleeve	4	
75	180 055 07 71	Expanding screw	4	

10/024