

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>TOOLS</u>		
1	000 583 35 15	Car jack	1	
2	120 581 01 46	Combination wrench, opening 17	1	
3	121 580 00 03	Tools bag with tools	1	
4	186 585 00 01	Tools bag	1	
5	120 581 00 60	Mounting fork	1	
6	120 581 06 65	Double end hex. -hd. socket screw wrench, opening 14 (for filling in and draining oil at transmission, rear axle and fuel outlet)	1	
7	000 581 01 17	Screw driver in 3 parts	1	
8	198 581 00 36	Spark plug wrench with handle, opening 21	1	
9	000 583 02 47	Air pressure gauge 0.5 - 3 atü	1	
10	136 580 00 10	Box with spare fuses	1	
		<u>ACCESSORIES</u>		
11	183 580 01 93	Key wallet	1	
12	-	Key ring N 397 b (for safety and door key)	1	

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
13	-	Chassis plate FU 3 N 202	1	
14	-	Grooved nail 3 x 6 DIN 1476	2	
15	-	Type plate WU 8 N 202	1	
16	-	Lens-hd. screw S 2, 9x6, 5 DIN 7981	4	