



Table 1

## ENGINE HOUSING

Group 01

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>ENGINE</u>		
-	121 010 00 00	Engine, complete without starter motor, fan, clutch and transmission	1	
		<u>CYLINDER CRANKCASE</u>		
1	121 010 11 08	Cylinder crankcase	1	
2	121 011 01 11	Crankshaft bearing cap	2	) optional ) for 1st and 3rd ) crankshaft ) bearing cap
-	121 011 04 11	Crankshaft bearing cap	2	
3	121 010 01 23	Crankshaft bearing cap with dowel pin	1	) optional ) for 2nd ) crankshaft ) bearing
-	121 010 06 23	Crankshaft bearing cap with dowel pin	1	
4	121 991 00 41	Dowel pin	4	
5	120 011 00 52	Guard plate half	2	)
-	120 011 01 52	Guard plate half ) 2.05 mm )	2	) )for crankshaft )bearing cap
-	120 011 02 52	Guard plate half ) 2.10 mm ) repair design	2	) ) )
-	120 011 03 52	Guard plate half ) 2.20 mm )	2	) )
6	121 990 12 40	Washer	5	)for crankshaft )bearing cap
7	-	Hex. -hd. screw M 12x75 DIN 931-10 K	6	)at cylinder )crankcase

10/024