



Table 22

PROPELLER SHAFT

Group 41

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>PROPELLER SHAFT</u>		
1	121 410 11 03	Propeller shaft, complete with intermediate bearing, without bearing bracket and rubber mounting	1	
2	180 410 11 01	Front propeller shaft with joint	1	
3	-	Grease fitting A 6 DIN 71412	2	
4	180 410 01 31	Universal cross	1	
6	120 997 01 88	Grease fitting	1	
15	186 410 04 30	Centering flange	1	
16	136 411 00 18	Ball socket, interior	1	
17	184 411 00 17	Centering ball	1	
18	136 411 01 18	Ball socket, exterior	1	
19	184 993 04 01	Pressure spring	1	
20	180 411 00 76	Locking plate	1	
25	121 410 22 02	Rear propeller shaft with bearing	1	
27	180 413 01 01	Housing	1	
28	-	Annular grooved bearing 6006 X - C 3 DIN 625	1	
29	180 413 01 51	Spacer ring	2	
30	180 997 03 40	Sealing ring	2	

Table 22

PROPELLER SHAFT

Group 41

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
31	-	Circlip 55x2 DIN 472	2	
32	-	Grease fitting A 6 DIN 71412	1	
33	-	Sealingring A 40x3 ac DIN 73102	2	
34	186 411 09 45	Joint flange	1	
35	182 994 00 43	Locking plate	1	
36	186 990 00 60	Grooved nut	1	
37	180 410 01 31	Universal cross	1	
38	120 997 01 88	Grease fitting	1	
44	-	Grease fitting A 6 DIN 71412	1	
50	182 990 00 01	Hex. -hd. screw	6)
51	186 994 03 25	Locking plate	3) for front at) rear propeller) shaft
52	-	Hex. nut M 8 DIN 934-5 S	6)
53	186 411 05 71	Fitted screw	3)
54	187 990 14 40	Washer	3) for joint disc) at front pro-
55	-	Castle nut M 12x1,5 DIN 937-5 S	3) peller shaft
56	180 410 03 39	Bearing bracket	1)
57	180 413 01 12	Rubber mounting	1) for propeller) shaft inter-) mediate bearing

Table 22

PROPELLER SHAFT

Group 41

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
60	180 411 06 15	Joint disc	1	
61	180 997 10 40	Sealing ring	1	
62	186 411 01 71	Fitted screw	3)
63	187 990 14 40	Washer	6)
64	-	Castle nut M 12x1,5 DIN 937-5 S	3)for joint disc)at transmission
65	-	Cotter pin 3x28 DIN 94	6)
66	120 411 00 80	Sealing ring (for propeller shaft at transmission)	1	
67	182 990 00 01	Hex. -hd. screw	6)
68	186 994 03 25	Locking plate	3)for propeller)shaft at
69	-	Hex. nut M 8 DIN 934-5 S	6)rear axle
71	180 411 02 62	Washer	2)
72	-	Toothed washer A 8,4 DIN 6797	2)for intermed.)bearing at
73	-	Hex. -hd. screw M 8x18 DIN 933-8 G	2)frame
75	120 413 05 61	Protective plate for rubber mounting	1)
76	-	Lock washer B 8 DIN 127	1)for protective)plate at inter-
77	-	Hex. -hd. screw M 8x12 DIN 933-8 G	1)mediate)bearing