



Table 11

## ENGINE SUSPENSION

Group 22/24

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>ENGINE SUSPENSION, FRONT</u>		
1	121 220 08 16	Engine support, front, left	1	
2	121 220 09 16	Engine support, front, right	1	
3	-	Lock washer B 8 DIN 127	3	)for engine )support at )cylinder )crankcase
4	-	Hex. -hd. screw M 8x18 DIN 933-8 G	3	
5	120 223 04 12	Rubber mounting, left	1	
6	120 223 05 12	Rubber mounting, right	1	)for engine sus- )pension, front
7	-	Lock washer B 12 DIN 127	2	
8	-	Hex. -hd. screw M 12x40 DIN 931-8 G	2	)for rubber )mounting at )engine support
9	-	Lock washer B 8 DIN 127	4	
10	-	Hex. -hd. screw M 8x15 DIN 933-8 G	4	)for rubber )mounting at )front axle )support
		<u>ENGINE SUSPENSION, REAR</u>		
15	121 223 18 04	Engine support, rear, left	1	
16	121 223 19 04	Engine support, rear, right	1	
17	-	Lock washer B 8 DIN 13	4	
18	-	Hex. -hd. screw M 8 x 25 DIN 933-8 G	4	
19	120 223 04 12	Rubber mounting, left (for engine suspension, rear)	1	