

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
59a	120 990 32 40	Adjusting washer	2	
60	120 330 01 87	Eccentric bushing	2	
61	-	Lock washer B 10 DIN 127	2	
62	-	Hex. nut M 10 DIN 934-5 S	2	
63	120 333 00 73	Locking plate	2	
64	-	Lock washer B 6 DIN 127	2	
65	-	Hex. -hd. screw M 6x10 DIN 933-8 G	2	
		<u>TIE ROD</u>		
66	120 330 07 03	Tie rod	2	when mounting take care that the grease fitting A 8 DIN 71412 is always mounted on outside (at disc wheel)
67	120 338 01 15	Tie rod jacket	2	
68	120 338 00 63	Tightening ring	4	
69	120 994 00 15	Locking plate	4	
70	120 330 05 48	Ball socket head (right-hand thread) (for tie rod, right, outside)	1	) ) grease fitting ) A 8 DIN 71412
71	120 330 04 48	Ball socket head (left-hand thread) (for tie rod, left, outside)	1	) mounted on ) inside ) )

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
71a	121 330 07 48	Ball socket head(right-hand thread) (for tie rod, left, inside)	1	) grease fitting 120 997 00 88 ) mounted on ) outside
71b	121 330 06 48	Ball socket head(left-hand thread) (for tie rod, right, inside)	1	
72	-	Hex. nut M 14x1, 5 DIN 936-5S	2	
73	-	Hex. nut M 14x1, 5 left DIN 936-5 S	2	
84	120 338 00 57	Sealing cover	4	
85	120 338 01 97	Boot	4	
86	120 990 01 55	Castle nut	4	
87	-	Grease fitting A 8 DIN 71412	2	
88	120 997 00 88	Grease fitting	2	
88a	-	Cotter pin 2x25 DIN 94 (for tie rod at steering lever and steering knuckle)	4	
89	186 333 00 65	Rubber buffer	4	
90	-	Lock washer B 12 DIN 127	8	) for wishbone, ) bottom at front ) axle support
91	-	Hex. -hd. screw M 12x1, 5x28 DIN 961-8 G	8	
92	120 333 00 71	Screw	4	) for wishbone, ) top at front ) axle support
93	-	Lock washer B 12 DIN 127	4	

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
94	-	Hex. nut M 12x1, 5 DIN 934-5 S (for wishbone, top at front axle support)	4	
		<u>FRONT AXLE SUSPENSION</u>		
95	180 333 02 65	Rubber buffer, in one piece (for mounting front axle support, front)	1	)
				)
				)
96	120 333 19 65	Rubber buffer, bottom	1	) for front sus-
97	120 333 04 53	Spacer sleeve	1	) pension of
98	120 330 01 55	Plate	1	) front axle
99	120 994 00 13	Locking plate	1	) support at
				) body
100	120 990 14 01	Hex. -hd. screw	1	)
				)
101	180 333 01 65	Rubber buffer, in one piece (for mounting front axle support, rear)	2	)
				)
				)
102	120 333 19 65	Rubber buffer, bottom	2	)
				) for rear sus-
103	120 333 04 53	Spacer sleeve	2	) pension of
				) front axle
104	120 330 01 55	Plate	2	) support at
				) body
105	120 994 00 13	Locking plate	2	)
				)
106	120 990 14 01	Hex. -hd. screw	2	)