

The distance can be varied by changing the position of the end plate in relation to the transmission (see Fig. 29-5/1).

If the distance is too large the clutch pedal will be difficult to operate because the pull of the compensating spring increases.

With the inside type of compensating spring the installed length "c" should be 137 mm in the case of Models 180, 180 D, and 190 SL and 155 mm in the case of Model 220 a.

18. Adjust the clutch pedal free play (see Fig. Job No. 29-3).

### **C. 4<sup>th</sup> Version with Swivel Support**

**Models 180, 180 a, 180 b, 180 D, 180 Db, 190 D, 190 Db, and 190 SL as well as 219, 220 S, and 220 SE with Mechanical Clutch**

On these models the removal and installation procedures for the clutch pedal shaft are the same as on Model 190.