



Table 16

REGULATION

Group 30

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>ACCELERATOR PEDAL CONTROL</u>		
1	121 301 06 01	Accelerator pedal	1	
2	121 301 00 82	Coating with fabric layer	1	
3	121 301 00 18	Bearing	2	
4	-	Hex. -hd. screw M 6x15 DIN 933-8 G	4))for bearing)at dashboard
5	-	Lock washer B 6 DIN 127	4)
6	183 997 00 81	Rubber grommet (for accelerator pedal through dashboard)	1	
7	121 300 03 20	Control shaft	1	
8	121 302 00 14	Lever (for release spring)	1	
9	180 993 17 10	Release spring (for accelerator pedal)	1	
10	180 990 00 17	Fixing screw	1))for acc. pedal
11	-	Hex. nut M 6 DIN 934-5 S	1))at control
12	-	Circlip G 12x1, 2 N 55 e	1))shaft and)bearing
13	121 301 02 15	Thrust rod	1	
14	180 301 00 97	Damper ring	2))for thrust rod
15	-	Washer 8, 4 DIN 125	4))at control)and double
16	-	Cotter pin 2x15 DIN 94	2))lever

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>CHOKE</u>		
17	180 300 06 30	Choke	1	
18	-	Spring steel wire III 1, 5 Ø DIN 2076, 990 mm lg.	1)
19	000 988 01 72	Wire coil 900 mm long	1)state length)when ordering
20	-	Insulating hose B 5x6, 2 DIN 40621, 880 mm lg.	1)
21	000 997 20 40	Felt ring	1)for choke at
22	120 302 04 01	Button	1)switchboard
		<u>IGNITION TIMING</u>		
23	180 300 00 32	Wire cable (for ignition timing)	1	
24	000 997 16 81	Rubber grommet (for ignition timing through bracket)	1	
25	000 997 18 81	Rubber grommet (for choke through dashboard)	1	
26	180 997 09 81	Rubber grommet	2)for choke at
27	180 302 00 72	Adjusting nut	1)carburettor