

Table 14

TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
44	136 265 00 81	Key (for shift rail mounting)	1	
45	136 350 01 90	Fan (at transmission case cover, top)	1	
46	120 260 21 37	Lever (for shifting shaft)	1	
47	186 260 01 50	Rubber ring	1	
48	-	Hex. -hd. screw M 6x25 DIN 931-8 G	1)) for lever at shifting shaft
49	-	Lock washer B 6 DIN 127	1	
50	-	Hex. nut M 6 DIN 934-5 S	1	
51	186 261 01 79	Gasket (for transmission case cover, top)	1	
52	-	Lock washer B 8 DIN 137	4)for transmission case cover, top at transmission case
53	-	Hex. -hd. screw M 8x30 DIN 931-8 G	4	
<u>SHIFTING, STEERING COLUMN</u>				
65	180 260 01 82	Shifting tube	1	
66	180 268 01 39	Guide pin	1	
67	186 997 00 82	Rubber ring	2	
68	186 268 02 73	Lock	1	
69	183 990 35 40	Shim	1	

Table 14

TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
70	186 268 02 74	Pin	1	
71	182 993 08 01	Pressure spring	1	
72	180 268 03 97	Sleeve	1	
73	180 268 00 24	Shifting lever	1	
74	183 268 00 92	Rubber pad	1	
75	180 268 00 57	Cap	1	
76	186 268 00 40	Shifting lever button, black	1	
-	186 268 01 40	Shifting lever button, ivory	1	special request
77	120 260 21 94	Bearing body with sleeve	1	
78	180 462 08 96	Sleeve (for steering passage)	1	
-	-	Button-hd. rivet 2,6x10 DIN 660 A1	3	
79	120 260 01 95	Rubber mounting, bottom	1	
80	-	Circlip A 18x1, 2 K N 55 b	1	
82	180 260 02 78	Intermediate shaft with ball pin	1	
83	000 981 22 10	Needle bearing HK 14	2	
85	180 997 09 40	Sealing ring	2	
86	180 990 23 40	Washer	2	
87	180 260 02 81	Intermediate lever	1	

Table 14

TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
88	-	Hex. -hd. screw M 7x20 DIN 931-8 G	1)for clamping)intermediate)lever at inter-)mediate shaft
89	-	Lock washer B 7 DIN 127	1	
89a	000 546 18 41	Cable connector, 2 poles (for reverse drive lamp)	1	
89b	-	Cylindr. screw AM 4x12 DIN 84-5 S (for cable connector at bearing body, steering)	2	
90	180 260 02 37	Selector lever	1	
91	180 268 00 32	Selector lever shaft	1	
91a	312 990 03 40	Washer	1)
92	-	Hex. -hd. screw M 8x30 DIN 931-8 G	1)for selector)lever at)selector lever
93	-	Lock washer B 8 DIN 127	1)shaft)
94	-	Hex. nut M 8 DIN 934-5 S	1)
95	000 981 21 10	Needle bearing HK 12	2	
95a	180 997 08 40	Sealing ring	1	
95b	180 991 10 40	Spacer sleeve	1	
96	183 261 04 74	Pressure pin 40 mm long (for reverse drive lamp switch) (shorten pin as required)	1	
97	000 545 02 06	Reverse drive lamp switch	1	see also group 54

Table 14

TRANSMISSION

Group 26

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
113	180 462 03 96	Sleeve	1	
114	180 268 02 05	Dust cap	1	
115	180 268 00 80	Gasket	1	
116	-	Cyl. screw AM 4x8 DIN 84-4 S	2)for dust cap)at bearing)body
117	-	Lock washer B 4 DIN 127	2	
118	120 260 29 33	Shifting rod	1	
119	-	Hex. nut M 10 DIN 70616-5 S chromium-plated	1	
120	180 991 00 22	Ball socket	1	
121	-	Securing yoke S 13 DIN 71805 (for shifting rod at lever, bearing body)	1	
122	120 260 24 33	Selector rod	1	
123	-	Hex. nut M 10 DIN 70616-5 S chromium-plated	1	
124	180 991 00 22	Ball socket	1	
125	-	Securing yoke S 13 DIN 71805 (for selector rod at lever, bearing body)	1	
126	-	Lock washer 8 N 55 a	2))for mounting)shifting and)selector rod)
127	183 990 42 40	Washer	2	
128	-	Cotter pin 2 x 15 DIN 94	2	