



Table 24

BRAKES, REAR WHEEL BRAKE

Group 42

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>REAR WHEEL BRAKE</u>		
1	180 420 12 17	Brake anchor plate, rear, left	1	
2	180 420 13 17	Brake anchor plate, rear, right	1	
3	180 423 02 71	Pin	4)for automatic
4	-	Lock washer B 14 DIN 127	4)brake adjustment)at brake anchor plate
5	121 420 01 20	Brake shoe, front, left with 2 different brake linings	1	
6	121 420 02 20	Brake shoe, front, right with 2 different brake linings	1	
7	180 421 05 10	Brake lining)for replacement	2	
8	183 990 02 95)delivery(to rivet, Tubular rivet)unpasted)	20	
9	121 420 03 20	Brake shoe, rear with 2 different brake linings	2	
10	180 421 05 10	Brake lining)for replacement	2	
11	183 990 02 95)delivery (to rivet Tubular rivet)u npasted)	20	
12	180 423 05 50	Adjusting sleeve	4)
13	180 990 09 40	Pressure plate)	8)for automatic
-	180 990 24 40) optional Pressure plate)	8)brake adjust-)ment at brake)shoe
14	180 421 00 32	Friction washer	8)
15	194 993 00 01	Pressure spring	4)

Table 24

BRAKES, REAR WHEEL BRAKE

Group 42

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	180 421 03 71	Tightening screw	4)for automatic)brake adjust-)ment at brake)shoe
-	180 990 13 40	Shim	a. r.	
		<u>BRAKE LEVER</u>		
17	180 420 00 42	Brake lever, left	1)for brake an-)chor plate at)rear axle tube
18	180 420 01 42	Brake lever, right	1	
20	000 997 81 47	Sealing ring (in rear axle tube)	2	
21	120 357 01 79	Gasket	2	
22	120 357 00 58	Gasket holder	2	
23	000 997 88 47	Sealing ring	2	
24	-	Lock washer B 7 DIN 127	12	
25	-	Hex. -hd. screw M 7x18 DIN 933-8 G	12	
26	120 993 07 01	Pressure spring	2	
27	120 990 06 40	Washer)	2	
28	120 423 01 56	Washer) for supporting tube	2	
28a	120 990 07 40	Washer)	2	
29	-	Lock washer B 8 DIN 127	2	
30	-	Hex. -hd. screw M 8x15 DIN 933-8 G	2	