

Table 17

## SPRINGS AND SUSPENSION

Group 32

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
15	-	Lock washer B 7 DIN 127	8	)for shock ab-
16	-	Hex. nut M 7 DIN 934-5 S	8	)sorber at wish-
17	180 323 01 85	Rubber ring, top	2	)bone, bottom
18	120 323 06 85	Rubber ring, bottom	2	)
19	180 323 00 83	Plate	2	)for shock ab-
20	-	Hex. nut M 10x1 DIN 934-5 S	4	)sorber at front
		<u>REAR SPRING</u>		)axle support
21	121 324 20 04	Rear spring, left	1	)
22	121 324 21 04	Rear spring, right	1	)
23	180 325 04 15	Spring retainer, bottom	2	)for shock ab-
24	180 325 01 44	Rubber mounting	2	)sorber at front
25	180 325 03 15	Spring retainer, top	2	)
26	180 325 00 52	Spacer ring, top	a. r.	)axle support
27	180 320 00 44	Rubber buffer lock	2	)
28	-	Lock washer B 7 DIN 127	4	)
29	-	Hex. -hd. screw M 7x15 DIN 933-8 G	4	)for rubber
		<u>SHOCK ABSORBER, REAR</u>		)buffer at body
30	121 320 03 31	Shock absorber, rear	2	)
				optional with 000 326 41 00

19/024