

When ordering spare parts do not fail to quote:

Engine type (model)	with engine number)
e.g. M 121 B. I/121. 920	65 00010)
)
Chassis type (model)	with chassis number)
e.g. 190/121.010	65 00010) see table I
)
Body number	Body number plate)
e.g. A 121.010 65 00010	left front wall pillar,)
	between hinges.)
Part number:	see column "part number"	
Exact designation:	see column "Nomenclature"	
	A dash (-) in column part number indicates that the entire designation in column "Nomenclature" must be quoted.	

When ordering spare parts for units, also state the number of these units:

Transmission number:	stamped in transmission housing)
)
Front axle number:	at steering knuckle, left and right)
) see table II
Rear axle number:	stamped in rear axle case, bottom)
)
Steering number:	stamped in steering case cover)

When ordering keys, please indicate the respective key number, which can be found:

for the lockable handle and lock-)
) at the cylindrical body of the lock
 able luggage compartment lid)

(Locking of door handle and luggage compartment lock is of the same type).

Carefully note the engine, chassis, and body numbers of your car.

Our customers are requested to place spare parts orders with our branches and agencies only.

DAIMLER-BENZ AKTIENGESellschaft

Stuttgart-Untertürkheim

VII