



Table 34

BODY, FRAME FLOOR

Group 61

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>FRAME FLOOR</u>		
1	10 120 610 02 17	Cross tube, front, complete	1	
2	10 120 610 00 36	Bracket (for bumper, front)	2	
3	10 120 612 00 31	Support (for horn)	1	
4	10 121 612 01 43	Support, left	1) for radiator) mounting
4a	10 121 612 02 43	Support, right	1	
5	10 120 610 01 77	Side member half, front, top, left	1	
6	10 120 610 02 77	Side member half, front, top, right	1	
6a	120 427 00 27	Stop (for locking hand brake lever)	1	
6b	120 427 02 74	Pin (for hand brake lever)	1	
6c	120 293 05 17	Tube (for pedal mounting)	1	
7	10 180 612 02 21	Housing (for rear axle suspension, top)	1	
8	180 427 05 41	Bracket (for brake cable, left)	1	
9	180 427 06 41	Bracket (for brake cable, right)	1	
10	10 180 612 01 21	Housing (for rear axle suspension, bottom)	1	

10/024

Table 34

BODY, FRAME FLOOR

Group 61

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
11	10 120 612 00 23	Bracket (for brake fluid line, rear, right)	1	} rear, right } for taking up } single-joint } axle
12	10 120 610 00 12	Bracket (for brake fluid line, rear, left)	1	
13	000 990 12 20	Cylindr. screw	1	
14	10 180 610 00 31	Support	1	
15	10 180 612 00 43	Support, outside	1	
16	10 180 612 01 43	Support, inside	1	
17	10 120 610 01 10	Side member, top, rear, left	1	
18	10 120 610 02 10	Side member, top, rear, right	1	
19	10 120 610 00 18	Cross member, front	1	
20	10 120 611 01 47	Mounting (for car jack, front)	2	
21	10 120 610 03 77	Forked member, bottom, left	1	
22	10 120 610 04 77	Forked member, bottom, right	1	
23	10 120 611 01 22	Side member support, top, left	1	
24	10 120 611 02 22	Side member support, top, right	1	
25	10 120 611 01 21	Side member half, top, outside, left	1	
26	10 120 611 02 21	Side member half, top, outside, right	1	
27	10 120 611 00 33	Support (for entrance sill)	1	

Table 34

BODY, FRAME FLOOR

Group 61

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
28	10 180 610 01 13	Support (for car jack, left)	1	
29	10 180 610 02 13	Support (for car jack, right)	1	
31	10 120 611 03 20	Side member half, rear, bottom, left	1	
32	10 120 611 04 20	Side member half, rear, bottom, right	1	
33	10 180 610 00 58	Cup (for shock absorber mounting)	2	
34	10 120 611 03 22	Side member support, bottom, left	1	
35	10 120 611 04 22	Side member support, bottom, right	1	
36	10 120 611 03 21	Side member half, bottom, outside, left	1	
37	10 120 611 04 21	Side member half, bottom, outside, right	1	
40	10 120 610 00 16	End cross member	1	
41	10 120 610 00 25	Reinforcement (for supporting exhaust tube, rear)	2	
42	10 120 610 00 38	Bracket (for fuel tank suspension, rear)	1	
43	000 990 14 20	Cylindr. screw	1	

10/024

Table 34

BODY, FRAME FLOOR

Group 61

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
43a	10 120 616 01 67	Main floor, left	1	
43b	10 120 616 02 67	Main floor, right	1	
44	10 120 610 01 62	Floor, rear	1	
45	10 120 610 03 75	Spare wheel recess, left	1	
46	10 120 610 04 75	Spare wheel recess, right	1	
47	10 120 610 00 37	Bracket (for fuel tank)	2	
48	000 990 14 20	Cylindr. screw	2	
49	10 120 616 00 76	Spacer cup, front (at forked member, left and right)	2	
49a	10 121 610 00 79	Toe-board	1	
50	120 330 09 61	Mounting (for front axle)	3	
50a	120 331 00 72	Nut	3	
51	10 120 616 01 26	Spacer cup 1.5 mm high)) optional	1))	
-	10 120 616 02 26	Spacer cup 2.5 mm high)for mount-)ing, front	1))	
-	10 120 616 03 26	Spacer cup 3.5 mm high)(height) of center	1))	welded at cross tube, front, center
-	10 120 616 04 26	Spacer cup 4.5 mm high) of cup))	1))	
-	10 120 616 05 26	Spacer cup 5.5 mm high))	1))	
-	10 120 616 06 26	Spacer cup 6.5 mm high)	1)	

Table 34

BODY, FRAME FLOOR

Group 61

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	10 120 616 07 26	Spacer cup 7.5 mm high) optional) for mount-	1) welded at) cross tube,) front center
-	10 120 616 08 26	Spacer cup 8.5 mm high) ing. front) height	1	
-	10 120 616 09 26	Spacer cup 9.5 mm high) of center) of cup)	1	
52	120 460 04 35	Bracket (for steering shock absorber at side member half, left)	1	
56	180 350 01 33	Mounting for brace (left and right for rear axle)	2	
57	121 481 00 40	Support (for main brake cylinder)	1	
59a	10 120 890 00 10	Bracket (for car jack wrench, rear)	1	bracket for car jack wrench, front see group 64
60	10 120 610 08 66	Driver's seat support, center	1	
61	10 120 616 07 69	Driver's seat support, left, external	1	
62	10 120 616 08 69	Driver's seat support, right, external	1	
63	10 120 616 00 70	Rear seat support, front	1	
64	10 120 616 01 70	Rear seat support, left, external	1	
65	10 120 616 02 70	Rear seat support, right, external	1	

10/024