

Table 42

INTERIOR APPOINTMENTS

Group 81

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
14	10 121 810 01 30	Ash-tray (with roller guide)	1	
-	10 120 810 19 30	Ash-tray)) optional	1) up to chassis No. 65 00769
-	10 120 810 03 30	Ash-tray)	1	
16	10 121 810 00 30	Pull-type ash tray (with roller guide)	1	from chassis No. 65 00770
18	10 120 813 04 33	Plate for ash tray	1	
-	-	Toothed washer A 3,2 DIN 6797	1) for plate) at ash tray
-	-	Button-hd. screw AM 3 x 5 DIN 7986	1	
-	-	Button-hd. screw AM 3 x 8 DIN 7986 (for plate at ash tray)	1	up to chassis No. 65 00769
19	120 545 02 37	Button	1	
20	120 545 00 72	Rosette	1	
-	-	Toothed washer A 4,3 DIN 6797	1) for button and) rosette at) ash tray
-	-	Button-hd. screw AM 4x20 DIN 7986	1	
-	-	Countersunk screw S 3, 9x13 DIN 7982	3) for ash tray) at front wall)
21	000 994 13 45	Nut	3	
23	10 180 810 00 30	Ash tray (for rear door)	2	

10/024