



Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
1	10 120 682 02 04	Damping, toe-board, left	1) bitumen
2	10 120 682 01 04	Damping, toe-board, right	1) felt
3	10 120 682 01 06	Damping,) passage, front)	1	bitumen felt
4	10 120 682 02 13	Damping,) passage, front)	1	waffle felt
5	10 120 682 00 07	Damping,) center passage)	1	bitumen felt
6	10 120 682 00 14	Damping,) center passage)	1	waffle felt
7	10 120 682 00 16	Damping, seat, center	1	bitumen felt
8	10 120 682 01 01	Damping, driver's seat floor, front	2)
9	10 120 682 02 01	Damping, driver's seat floor, rear	2) bitumen felt
10	10 120 682 01 12	Damping, toe-board, left	1)
11	10 120 682 02 12	Damping, toe-board, right	1) waffle felt
13	10 120 682 00 05	Damping, passage in rear compartment	1)
14	10 120 682 00 02	Damping, bed in main floor	6) bitumen felt
15	10 120 682 00 08	Damping, rear compartment floor	2)
16	10 120 682 01 09	Damping center passage below rear seat	2) bitumen felt
17	10 120 682 00 09	Damping below rear seat, left	1)

10/024

Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
18	10 120 682 02 09	Damping below rear seat, right	1	bitumen felt
23	10 180 682 01 10	Damping, intermediate wall behind back rest of rear seat	1	jute felt
24	10 120 680 01 28	Damping, glove box, left	1	
25	10 120 680 02 28	Damping, glove box, right	1	
26	10 120 680 01 25	Damping, instrument panel, top, right	1	
27	10 120 680 02 25	Damping, instrument panel, top, left	1	
28	10 120 680 06 25	Damping, dashboard, upper part (below instrument panel)	1	
29	10 120 680 05 29	Damping, cowl, left (in engine space)	1	
-	-	Lens-hd. countersunk screw S 3, 5 x 22 DIN 7983 chrom. -plated	1))for damping)at cowl, left
30	000 985 12 62	Countersunk washer	1)
31	10 120 680 08 29	Damping, cowl, right	1	
-	-	Lens-hd. countersunk screw S 3, 5 x 22 DIN 7983 chrom. -plated	4))for damping)at cowl, right
-	000 985 12 62	Countersunk washer	4)
32	10 180 680 01 76	Partition, left	1	
33	10 180 687 01 70	Damping at partition, left	1	
34	10 180 687 00 12	Angle	2	

Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	-	Lens-hd. screw AM 5x12 DIN 7985	2)
-	-	Washer 5, 3 DIN 433	2)
-	-	Lock washer A 5 DIN 137	2) for angle at partition, left
-	-	Hex. nut M 5 DIN 934-5 S	2)
-	-	Lens-hd. screw AM 4x12 DIN 7985	1)
-	-	Lock washer B 4 DIN 127	1) for partition at air duct
-	-	Washer A 4 DIN 9021	1)
35	10 180 680 02 76	Partition, right	1	
36	10 180 687 02 70	Damping at partition	1	
37	10 180 687 00 12	Angle	1	
-	-	Lens-hd. screw AM 5x12 DIN 7985	1)
-	-	Washer 5, 3 DIN 433	1) for angle at partition,
-	-	Lock washer A 5 DIN 137	1) right
-	-	Hex. nut M 5 DIN 934-5 S	1)
38	10 121 830 00 50	Bracket (for heater tube)	1	
-	-	Countersunk screw AM 6x15 DIN 7987 (for bracket at cowl)	1	
39	120 993 16 10	Tension spring (for partition at dashboard)	1	

Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
40	10 121 680 01 56	Bracket (for ATE booster brake)	1	only valid if ATE booster brake is installed upon spec. request
41	000 987 10 36	Rubber profile 40 mm long	1	state length when ordering
42	10 180 687 00 70	Damping at bracket ATE booster brake	1	
43	10 121 687 01 70	Damping at bracket ATE booster brake	1	
44	000 987 10 36	Rubber profile 250 mm long	1	state length when ordering
-	-	Hex.-hd. screw M 6x15 DIN 933	4) for bracket at) dashboard
-	-	Lock washer B 6 DIN 127	4	
45	10 180 680 01 58	Bracket for fuse box	1	
46	10 180 687 03 70	Damping at bracket fuse box	1	
47	000 987 10 36	Rubber profile 230 mm long	1	state length when ordering
-	-	Lens-hd. screw Z 4, 2x19 DIN 7981 (for bracket, fuse box, at bracket for ATE booster brake)	2	
48	10 180 687 04 70	Seal (for bracket, ATE booster brake)	1	
49	10 180 687 01 97	Seal, left, at wheel house)	1	

Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
50	10 180 687 02 97	Seal, right, at wheel house	1	
55	10 120 680 09 29	Damping, cowl, center, bottom (in engine space)	1	
-	-	Lens-hd. countersunk screw S 3, 5x22 DIN 7983 chrom. -plated	5) for damping,) center, at) cowl
-	000 985 12 62	Countersunk washer	5	
56	10 120 680 06 29	Damping, cowl, center, top (in engine space)	1	
57	10 120 682 00 51	Damping, top 70x6x1250 mm long	7	jute felt with paper insert
58	10 120 688 07 06	Lining, front wall, lateral, bottom, left	1	
59	10 120 688 08 06	Lining, front wall, lateral, bottom, right	1	
-	-	Lens-hd. countersunk screw S 2, 9x9, 5 DIN 7983 chrom. -plated	2) for lining at) front wall,) lateral,) bottom
60	000 985 05 62	Countersunk washer	2	
61	10 120 688 01 20	Fixing rail, front, bottom, left	1) for front wall) lining
62	10 120 688 02 20	Fixing rail, front, bottom, right	1	
-	-	Countersunk screw Z 3, 9x13 DIN 7982 chrom. -plated	7) for fixing rail) at front wall,) lateral
-	-	Countersunk screw S 3, 9x9, 5 DIN 7982 chrom. -plated	1	

10/024

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
63	000 993 41 86	Lining, front wall, instrument panel, bottom and top	1	state colour, length and width when ordering
64	10 120 689 05 85	Lining (for instrument panel, lateral, left)	1	
65	10 120 689 06 85	Lining (for instrument panel, lateral, right)	1	
66	000 988 77 78	Clip, round	2) for lateral) lining at) angle plate
67	120 991 02 07	Pin	2	
-	000 994 16 45	Clip)) optional	4	
70	000 994 04 45	Clip)	4) for lining at) partition,) external
-	-	Lens-hd. countersunk screw Z 4, 2x13 DIN 7983	4	
-	-			
71	10 120 680 04 83	Cover (for glove box)	1	
73	10 120 689 00 70	Handle (for glove box)	1	
-	-	Countersunk screw AM 3x8 DIN 7987	3	for handle at cover
74	10 120 680 01 84	Ball-type latch	1	
75	10 120 680 03 87	Hinge, left)) for glove box cover	1	
76	10 120 680 04 87	Hinge, right)	1	
-	-	Countersunk screw AM 4x6 DIN 7987 (for hinge at cover)	4	

Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	000 994 16 45	Clip)	4)
77	000 994 04 45) optional Clip)	4) for glove box cover at in-
-	-	Lens-hd. countersunk screw S 4, 2x13 DIN 7983	4) strument panel)
78	10 120 689 00 41	Support (for glove box cover)	1	
-	-	Lens-hd. countersunk screw S 2, 9x6, 5 DIN 7983 chrom. -plated	1)) for support at
-	-	Lens-hd. screw Z 2, 9x6, 5 DIN 7981	2) glove box,) shell plate)
80	10 120 680 03 11	Mounting plate (for control buttons)	1	
81	10 120 689 00 24	Washer (for charging control lamp)	1	
-	-	Lens-hd. screw S 3, 9x16 DIN 7981	3)) for mounting) plate at shell
-	-	Washer A 4 DIN 9021	3) plate))
83	000 994 13 45	Clip	3)
85	10 121 680 00 96	Cover, instrument panel, center	1	
86	10 120 689 02 39	Cover	1	
87	10 121 817 00 14	Type designation plate, interior at instrument panel	1	
88	000 994 00 45	Spring nut (for type designation plate at cover)	2	

Table 37

LINING AND TRIMMING

Group 68

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	000 994 04 45	Clip)	4)
) optional)
-	000 994 16 45	Clip)	4)for cover,
)center at
-	-	Lens-hd. countersunk screw Z 4, 2x13 DIN 7983	4)partition
)
89	10 120 680 00 75	Cover plate (at instrument panel)	1	state colour when ordering
-	000 983 45 86	Covering	1	state colour, length and width when ordering
-	000 985 09 62	Countersunk washer	2)for cover plate
)at shell plate,
-	-	Lens-hd. countersunk screw S 2, 9x9, 5 DIN 7983 chrom. -plated	2)glove box
)
90	10 120 689 01 71	Ornamental moulding (for instrument panel)	1	
91	000 988 58 78	Clamp	6)for ornamental
)moulding at
92	000 988 47 78	Expanding clip	4)instr. panel