

Table 31

RADIATOR

Group 50

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
15	-	Lock washer B 6 DIN 127	4)for leaf spring
16	121 504 00 38	Threaded plate	2)at bracket for)body cross re-)inforcement
17	-	Lock washer B 8 DIN 137	2)
18	-	Hex. nut M 7 DIN 934-5 S.	2)for leaf spring)at radiator
18a	-	Washer 7, 4 DIN 125	2)
<u>COOLING WATER LINE</u>				
19	-	Rubber hose 32x40x70 N 272 (between cooling water thermostat and cooling water discharge nipple)	1)))state length)when ordering
19a	-	Rubber hose 32x40x70 N 272 (between cooling water line and cooling water thermostat)	1)))
20	-	Hose clamp S 9 N 262	4)for rubber hose)at cooling water
21	-	Hose strap 9x0, 4x300 N 263 (state length when ordering)	4)thermostat and)cooling water)discharge nipple
22	000 203 65 75	Cooling water thermostat, compl.	1	
23	-	Rubber hose 12x18x260 N 272	1	state length when ordering
24	-	Hose clamp S 9 N 262	2	
25	-	Hose strap 9x0, 4x165 N 263	2	state length when ordering

Table 31

RADIATOR

Group 50

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
26	-	Rubber hose 38 x 46 x 70 N 272 (state length when ordering)	2) for cooling) water line,) bottom) from radiator) to engine and) distributor tube,) cooling water) return flow
27	-	Hose clamp WSN 9 N 262	4	
28	-	Hose strap 9 x 0,4 x 380 N 263	4	
29	121 500 00 91	Distributor tube (for cooling water return flow and heating)	1	