

Table 18

FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
15	120 332 01 62	Pressure plate, bottom	2	
16	120 332 02 62	Pressure plate, top	2	
17	136 332 00 52	Shim 2.30 mm thick)	2)
))
-	136 332 01 52	Shim 2.50 mm thick)	2)
))for king pin
-	136 332 02 52	Shim 2.70 mm thick)	2)at steering
) optional)knuckle,
-	136 332 08 52	Shim 1.70 mm thick)	2)bottom
))
-	136 332 09 52	Shim 1.90 mm thick)	2)
))
-	136 332 10 52	Shim 2.10 mm thick)	2)
18	120 333 05 09	Steering knuckle support	2	
19	-	Grease fitting A 8 DIN 71412	2	
20	181 994 00 15	Locking plate	2	
21	-	Hex. nut M 14 x 1, 5 DIN 934-5 S	2	
		<u>FRONT WHEEL HUB</u>		
22	180 330 07 25	Front wheel hub with pin	2	
23	120 401 01 71	Wheel fixing pin	10	
24	-	Tapered roller bearing 32206 DIN 720	2	
25	180 334 01 64	Puller ring)	2) for front wheel hub
26	000 997 18 46	Sealing ring)	2)

Table 18

FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
27	-	Tapered roller bearing 32303 DIN 720	2	
28	180 334 00 62	Intermediate ring (for front steering knuckle, left)	1	
29	180 334 01 62	Intermediate ring (for front steering knuckle, right)	1	
30	120 334 03 15	Washer (for steering knuckle without locking groove)	2	
31	120 334 07 72	Clamping nut M 16 x 1 (for left and right steering knuckle)	2	
33	120 990 13 20	Hex. -hd. socket screw M 7	2	
34	120 330 01 57	Wheel cap with contact spring	2	
34a	-	Grooved guide pin 4 x 10 DIN 1474 Ms	2	for radio inter- ference sup- pression
35	180 421 08 01	Brake drum	2	
36	120 990 00 59	Sph. collar nut (for brake drum at wheel pin, front wheel hub)	4	see also group 35 and 40
<u>WISHBONE, BOTTOM</u>				
37	120 330 12 08	Wishbone, bottom, left	1	
38	120 330 13 08	Wishbone, bottom, right	1	
39	120 990 10 20	Cylindr. screw	8	