

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
93	-	Sealing ring A 18x30x7 DIN 6503	1))for steering)intermediate
94	120 463 02 33	Cover	1)lever at)pivot pin
95	181 994 00 10	Locking plate	1)
96	-	Grease fitting A 8 DIN 71412	1	
100	121 460 09 05	Steering rod	1	
105	120 997 00 88	Grease fitting	2	
106	120 338 00 57	Sealing cover	2))for drag link
107	120 338 01 97	Boot	2)at pitman arm)and steering
108	120 990 01 55	Castle nut	2)intermediate)lever
109	-	Cotter pin 2x25 DIN 94	2)
		<u>STEERING SHOCK ABSORBER</u>		
110	000 463 15 32	Steering shock absorber	1	
111	120 990 12 01	Hex. -hd. screw	1)for steering)shock absorber
112	-	Lock washer B 10 DIN 127	1)at drag link)
113	-	Hex. nut M 10x1 DIN 936-5 S	1)
114	120 990 09 40	Washer	1))for steering
115	-	Lock washer B 10 DIN 127	1)shock absorber)at side member
116	-	Hex. nut M 10x1 DIN 936-5 S	1)half